


Enhanced Climate Control Connection Diagram

For Ducted VRV and VRF systems



DUCTED VRV or VRF indoor unit



AIR CONDITIONER'S PROPRIETRY CONTROLLER (Optional)



SIGNAL RECEIVER UNIT



AIRTOPIA ENHANCED CLIMATE CONTROL



PUSH CONTROLLER (optional)



MOBILE



LAPTOP



INTERNET

For the control of an air conditioner's functions from a smart device or building automation system.


Refer to software installation guide or download app from app.airtopia.com

Control your air conditioner functions from your smart phone, tablet or computer.


Before connecting your air conditioner to an Airtopia controller please refer to the Airtopia Installation Guidelines.

Air Conditioner's Transmission wire


IR Transmission




C-BUS WALL SWITCH




EDLT WALL SWITCH



C-BUS TOUCH SCREEN CONTROLLER



WISER II



LAN

C-Bus (optional)